

## how to fold your



1



2



3



4

1. Start by holding the decoy vertically out away from your body.
2. Grab the decoy with one hand: thumb pointing up, and the other hand thumb pointing down as shown.
3. To start folding, twist the hand with the thumb pointing up forward and the hand with the thumb pointing down backward.
4. As you start the twisting motion push inward like an accordion, continue to twist and push, then cross your hands and bring the decoy into your body.
5. The band in the decoy will form three rings, use a rubber band to hold the decoy closed. (Tip: tie the rubber band to the elastic attached to the leg so you never lose it.)
6. Congratulations, you've folded the decoy.

*Enclosed is one leg pole, insert into a sleeve sewn inside the decoy. The sleeve opening is located in the bottom of the decoy. Slide the pole up into the sleeve and hook the elastic strip onto the ground stake peg. Step the pole stake into the ground and you're set up. (Tip: for a quick set up, tie a fish line loop at the top of the decoy and you can hang it on a limb without the leg pole.)*

We would love to have your success stories and pictures with our decoys, or even videos. You can send them to:

### Montana Decoy, Inc.

Jerry McPherson  
P.O. Box 2377 • 2690 Wagoneer Drive  
Colstrip, Montana 59323  
email: [jmcphers@montanadecoy.com](mailto:jmcphers@montanadecoy.com)  
Check out our web site at [www.montanadecoy.com](http://www.montanadecoy.com)  
Phone: 406-748-3092

MADE IN THE USA



**!** CAUTION

**The Montana Decoy looks so real that all precautions must be taken, another hunter might mistake the decoy for the REAL THING! ALWAYS WEAR HUNTER'S ORANGE WHEN USING THIS PRODUCT.**

TOM TURKEY