


# how to fold your



1



2



3



4



5



6

1. Start by holding the decoy vertically out away from your body.
2. Grab the decoy with one hand: thumb pointing up, and the other hand thumb pointing down as shown.
3. To start folding, twist the hand with the thumb pointing up forward and the hand with the thumb pointing down backward.
4. As you start the twisting motion push inward like an accordion, continue to twist and push, then cross your hands and bring the decoy into your body.
5. The band in the decoy will form three rings, use a rubber band to hold the decoy closed. (Tip: tie the rubber band to the elastic attached to the leg so you never lose it.)
6. Congratulations, you've folded the decoy.

Enclosed are three different support poles that are labeled "frontleg," "backleg," and "backbone." The backbone pole is inserted into a buttonhole next to an elastic strip on the rear end of the decoy. The pole is pushed all the way to the head. Then, hook the elastic strip over the end of the pole. Insert the rear leg pole into a sleeve at the bottom of the rear leg and hook the elastic strap into the adjustable hook on the leg pole. Do the same with the front leg pole into the frontleg.

We would love to have your success stories and pictures, or even videos. You can send them to:

### Montana Decoy, Inc.

Jerry McPherson  
P.O. Box 2377 • 2690 Wagoneer Drive  
Colstrip, Montana 59323  
email: [jmcperson@tgrsolution.net](mailto:jmcperson@tgrsolution.net)  
Check out our web site at [www.montanadecoy.com](http://www.montanadecoy.com)  
Phone: 406-748-3092



## CAUTION

The Montana Decoy looks so real that all precautions must be taken during archery season. Animals tend to be aggressive during the rut. Also, another hunter might mistake the decoy for the REAL THING! **DO NOT USE** the MONTANA DECOY during rifle season. The user of this product assumes all risk of injury in association with the use of this product.